

Adapter plate

The base plate is used as an adapter for system holders. The 16 part split allows to install the system holders at an angle of 22.5° in each case. The mounting holes are matched to the pipe clamp and swivel bearing.



No.	Type	Order no.	Material	Colour	PU pce.	Remarks
1	Base plate A6 (DH-RK 40-32)	82952620	Steel	Black	1	powder-coated
2	Base plate A6 (DH-RK 40-32)	82952092	Steel	Black	1	powder-coated

Pipe clamp

The pipe clamp enables clamping clips and precision tubes to be connected to other components. Clamping on the entire circumference of the tube. With holding flange for swivel bearing and base plate.



No.	Type	Order no.	Material	Colour	PU pce.	Remarks
1	Pipe clamp D30	82952616	Al	Silver	1	
2	Pipe clamp D32	82952610	Al	Silver	1	
3	Pipe clamp D34	82952614	Al	Silver	1	
4	Pipe clamp D40	82952612	Al	Silver	1	