

Ball joint

The ball joint is used for holding a dresspack in the system holder. This allows the conduit adequate freedom of movement, because it can rotate approx. 22° all directions once installed in the system holder. The cable sheath is guided in the flared piece in such a way as to allow it to slide.



| No. | Type | Order no. | Material | Colour | PU pce. | Remarks |
|-----|----------------------|-----------|----------|--------|---------|---------|
| 1 | End jaw NW 36 | 82951248 | POM | Black | 1 | |
| 2 | End jaw NW 48 | 82951250 | POM | Black | 1 | |
| 3 | Flared section NW 36 | 82951258 | POM | Black | 1 | |
| 4 | Flared section NW 48 | 82951260 | POM | Black | 1 | |